



 = Steps

- Excavate and install a new 6PE pumped STP towards the rear of the garden, this will require re-routing the inlet pipework leading from MH1 by approximately 8.0m, the garden slopes upwards towards the rear by maximum 0.65m so the inlet may have to be around 1.0m deep. A new 90.0m 32mm pumped main can then be excavated and installed leading from the tank, through the field at the rear and down to the stream at the rear. Before discharging to the stream, increase the pipe diameter to 100mm.
- Access will be by via side of property and field at rear. Electric duct ran to porch. Backfill old tank with spoil. Grassed surfaces to be topsoiled and seeded.