

Maintenance Schedule - Alligator & Mixbox

Maintenance	Maintenance conducted		Month	July			Month	August			Month	Sept		
Mixbox discharge pump	Weekly	Initials	HL	HL										
Diverter Valve Grease	Weekly	Initials	HL	HL										
Rubber bellows pipe joiners	Weekly	Initials	HL	HL										
Mixbox General	Weekly	Initials	HL	HL										
Alligator General	Weekly	Initials	HL	HL										
Mixbox feed pump	Weekly	Initials	HL	HL										
Grease Valve	Weekly	Initials	HL	HL										
Valve Gearbox	6 months	Initials												
Pump Gearbox	12 months	Initials	HL	HL										
Mixbox Pressure Gauges	Weekly	Initials	HL	HL										
Discharge Pressure Gauge	Weekly	Initials	HL	HL										
Feed Pressure Gauge	Weekly	Initials	HL	HL										
Alligator Effluent Tank	2 weeks	Initials		HL										
Hydrolic power pack	Weekly	Initials	HL	HL										
Hydrolic Rams & pins	Monthly	Initials	HL											

Maintenance Schedule - Prepit Pump

Maintenance	Maintenance conducted		Month	July			Month	August			Month	Sept		
Prepit Pump	Monthly	Initials	HL											
Grease Valve	Weekly	Initials	HL	HL										
Valve Gearbox	12 months	Initials												
Mixer	Weekly	Initials	HL	HL										
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												

Maintenance Schedule -Seperator

Maintenance	Maintenance conducted		Month	July			Month	August			Month	Sept		
Seperator Screen	2 weeks	Initials	HL											
Feed Pump	Monthly	Initials	HL											
Seperator Grease Gearbox	2 weeks	Initials	HL											
General	6 months	Initials												
Valves	Monthly	Initials	HL	HL										
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												

Maintenance Schedule -Pump Lagoon

Maintenance	Maintenance conducted		Month	July			Month	August			Month	Sept		
Lagoon Pump	3 Months	Initials												
Pipework	Weekly	Initials	HL	HL										
Valves	Weekly	Initials	HL	HL										
Submersible Pump Water	Monthly	Initials	HL											
Gearbox Oil Pressure	Monthly	Initials	HL											
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												

Maintenance Schedule -Generator

Maintenance	Maintenance conducted		Month	July			Month	August			Month	Sept		
Generator Backup	Monthly	Initials	HL											
Levels	Weekly	Initials	HL											
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												
		Initials												

Maintenance Schedule -Control Room

Maintenance	Maintenance conducted		Month	July			Month	August			Month	Sept		
Control Room Pump	6 months	Initials	HL											
Grease Valves	Weekly	Initials	HL	HL										
Valve Gearbox	12 months	Initials												
Pump Gearbox	12 months	Initials												
Air Compressor	Weekly	Initials	HL	HL										
Heating System	Monthly	Initials												
Pumps	Weekly	Initials	HL	HL										
Filters	Monthly	Initials												
Fuses / Trips	Weekly	Initials	HL	HL										
Pipework	Weekly	Initials	HL	HL										
Temp Gauges	Weekly	Initials	HL	HL										
Spill Kit Check	Weekly	Initial	HL	HL										